



IPPS-INTERACTIVELY PROGRAMMABLE PRESSURE SEQUENCER

Automatic generation of pressure sequences during package testing



Package testing often requires defined pressure sequences. The IPPS can be programmed with up to 99 different pressure sequences. The programming can be done by the user; special knowledge isn't necessary. Once programmed, the pressure sequences can be selected and activated. The duration of a sequence can vary from seconds to months.

BENEFITS:

- Defined pressure sequence with linear or step transitions
- Simple implementation of standard tests
- Interactive programming
- Menu-based user interface
- 10 pressure output connectors
- Numerical keyboard
- Water separator (for tests with gushing liquids)
- Pressure monitoring (optional - with MS version)

OPERATION:

The container to be tested is connected to one of the pressure output connectors. Pressure follows the programmed sequence.

TECHNICAL DATA:

Output pressure:	0 to 10 bar (0 to 145psi) 0 to 16 bar (0 to 230psi)
Input pressure:	up to 12/18 bar (174/261 psi)
Resolution:	0.1 bar (1.45 psi)
Min. step duration:	1 sec.
Media:	Neutral gases

Steinfurth Mess-Systeme GmbH

Elektromechanische Mess-Systeme
Bonifaciusring 15
45309 Essen
Deutschland
Telefon +49-201-85517-0
Telefax +49-201-85517-20
Internet: <http://www.steinfurth.de>
E-Mail: info@steinfurth.de

Steinfurth, Inc.

Electromechanical Measuring Systems
541 Village Trace
Bldg. 11, Suite 102
Marietta, GA 30067 USA
Phone +1-678-500-9014 & +1-404-918-5061
Telefax +1-678-840-7744
Internet: <http://www.steinfurth.com>
E-Mail: info@steinfurth.com

